## TRANSMISSION TOOLS 2



THE TRANSMISSION TOOLS SHOWN IN (P0004012) ARE APPLICABLE TO TR4A, TRIUMPH 250 & TR6. THESE ARE AS FOLLOWS: INSTALLATION SPACER. TRANSMISSION BALL RACE REMOVER/REPLACER ADAPTOR BLT2050-A/. THIS IS PART OF BLT2050/S4221A-15A KI1 WHICH ALSO CONTAINS BLT2050-1 (FAR RIGHT) & BLT2050-5 (DIRECTLY BELOW) MAINSHAFT BALL BEARING REPLACER BLT2027/S314 (USE WITH 18G1197 SHOWN IN TRANSMISSION TOOLS 1 OLD DUMMY LAYSHAFT. TRANSMISSION MAINSHAFT MAINSHAFT CIRCLIP REMOVER BLT2014/S69E INSTALLATION COLLAR. TRANSMISSION CASE HOLDER. SCREWS INTO DRAIN PLUG THREADED HOLE.